

SECTION TWO

ALPHABETICAL INDEX

Key words	Symbol No	Key words	Symbol No
A A C / D C converter' rectifier, substitute power supply	5003	Control, Treble	5037
Adapter, Telephone	5090	Correction, Instruction or	5105
Adjustment, Picture size	5067	Crispener	5059
Adjustment to a maximum	5147	Crystal piezo-electric pick-up	5088
Adjustment to a minimum	5146	Current, Alternating	5032
Aerial	5039	Current, Both direct and alternating	5033
Aerial, Frame	5042	Current, Direct	5031
Aerial (scanner) rotation	5129	Cutting	5171
Air impeller	5015	D Dangerous voltage	5036
Alternating current	5032	D C / A C converter	5194
Amplifier	5084	Dipole	5040
Amplitude, Horizontal picture	5065	Delicate items	5297
Amplitude, Vertical picture	5066	Direct and alternating current, Both	5033
Angle calibration	5202	Direct current	5031
Antenna	5039	Disk records, Pick-up for	5086
Anti rain-clutter (position of maximum)	5162	Drawing	5236
Anti rain-clutter (position of minimum)	5142	Dynamic pick-up, electro- or magneto-dynamic	5089
Anti sea-clutter (position of maximum)	5161	E Earphone	5076
Anti sea-clutter (position of minimum)	5141	Earth (ground)	5017
Attenuation, Signal strength	5044	Effect or action away from a reference point	5025
Automatic frequency control	5046	Effect or action in both directions away from a reference point	5027
B Badly soiled items, cooking utensils	5294	Effect or action in both directions towards a reference point	5028
Balance	5072	Effect or action towards a reference point	5026
Band-pass filter	5157	Electric shaver outlet	5225
Band-pass filter with variable centre frequency	5158	Electrodynamical pick-up	5089
Band-pass filter with variable pass-band, selectivity control	5159	End of text, Length or	5106
Band-stop filter	5160	Equipotentiality	5021
Bass control	5038	Erasing from an information carrier	5165
Battery check	5001	Erasing from tape	5097
Battery eliminator	5003	F Fast run	5108
Bearing marker	5133	Fast start	5177
Bearing ruler setting	5200	Fast stop	5178
Bell	5013	Filter, Band-pass	5157
Bidirectional microphone	5074	Filter, Band-stop	5160
Both direct and alternating current	5033	Filter, High-pass	5091
Brightness	5056	Filter, Low-pass	5092
Brilliance	5056	Filter with variable centre frequency, Band-pass	5158
Brilliance, Range rings	5144	Filter with variable pass-band, Band-pass	5159
C Camera, Colour television	5117	Focus	5055
Camera, Television	5116	Foot switch	5114
Cardioid microphone, Unidirectional or	5075	Frame aerial (U S A Loop antenna)	5042
Cell, Positioning of	5002	Frame or chassis	5020
Ceramic piezo-electric pick-up	5088	Fuse	5016
Chassis or frame	5020	G Gyro-compass true bearing	5198
Class II equipment	5172	Gyro indicator	5196
Clock, time switch, timer	5184	Gyro indicator setting	5197
Colour (qualifying symbol)	5048	H Heading marker	5128
Colour saturation	5058	Headphones	5077
Colour television	5050	Headphones, Stereophonic	5078
Colour television camera	5117	Headset	5079
Colour television monitor	5052	High-pass filter	5091
Colour television receiver	5054	High water level	5234
Colour video play-back	5123	Hiss filter (see Low-pass filter)	5092
Colour video recording	5121	Horizontal linearity	5068
Colour video tape recorder	5119	Horizontal picture amplitude	5065
Contrast	5057		
Control, Automatic frequency	5046		
Control, Bas	5035		